

HODNOTY PRŮTOKŮ VODOVODNÍCH BATERIÍ RAVAK

Průtok je udáván v l/min při tlaku 0,3 MPa

| RAVAK code | Umyvadlo | Bidet | Vana | Hlavová sprcha | Ruční sprcha | OUT 1 | OUT 2 | OUT 3 |
|-----------------------|----------|-------|------|----------------|--------------|-------|-------|-------|
| ES 012.XX | 5 | | | | | | | |
| ES 014.XX | 5 | | | | | | | |
| ES 015.XX | 5 | | | | | | | |
| ES 018.XX | 5 | | | | | | | |
| ES 019.XX.O1 | 5 | | | | | | | |
| ES 019.XX.O1.RB07B | 5 | | | | | | | |
| ES 021.XX.O1 | 18 | | | | | | | |
| ES 022.XX | | | 14 | | 16 | | | |
| ES 032.XX | | | 24 | | | | | |
| ES 056.XX | | 5 | | | | | | |
| ES 061.XX.O2 | | | | | | 19 | 22 | |
| ES 062.XX.O1 | | | | | | 25 | | |
| ES 063.XX.O2.RB07C | | | | | | 22 | 22 | |
| ES 065.XX.O2.RB07D.+S | | | | | 10 | | 16 | |
| ES 065.XX.O2.RB07E | | | | | | 12 | 12 | |
| ES 067.XX.O3.RB07C | | | | | | 22 | 22 | 22 |
| ES 068.XX.O3.RB07D.+S | | | | | 10 | | 17 | 16 |
| ES 068.XX.O3.RB07F | | | | | | 22 | 22 | 22 |
| EL 012.XX | 5 | | | | | | | |
| EL 014.XX | 5 | | | | | | | |
| EL 015.XX | 5 | | | | | | | |
| EL 019.XX.O1.RB07B | 5 | | | | 25 | | | |
| EL 022.XX | | | 13 | | 22 | | | |
| EL 032.XX | | | 25 | | | | | |
| EL 056.XX | | 5 | | | | | | |
| EL 061.XX.O2 | | | | | | 18 | 21 | |
| EL 062.XX.O1 | | | | | | 25 | | |
| EL 065.XX.O2.RB07D.+S | | | | | 10 | | 18 | |
| EL 065.XX.O2.RB07E | | | | | | 12 | 12 | |
| EL 068.XX.O3.RB07D.+S | | | | | 10 | | 17 | 18 |
| EL 068.XX.O3.RB07F | | | | | | 22 | 22 | 22 |

HODNOTY PRŮTOKŮ VODOVODNÍCH BATERIÍ RAVAK

Průtok je udáván v l/min při tlaku 0,3 MPa

| RAVAK code | Umyvadlo | Bidet | Vana | Hlavová sprcha | Ruční sprcha | OUT 1 | OUT 2 | OUT 3 |
|-------------|----------|-------|------|----------------|--------------|-------|-------|-------|
| PU 014.XX | 12 | | | | | | | |
| PU 015.XX | 12 | | | | | | | |
| PU 016.XX | 12 | | | | | | | |
| PU 019.XX | 15 | | | | | | | |
| PU 022.XX | | | 19 | | 11 | | | |
| PU 022.X1 | | | 19 | | 19 | | | |
| PU 026.XX | | | 21 | | 9 | | | |
| PU 032.XX | | | | | 23 | | | |
| PU 033.00 | | | | | 22 | | | |
| PU 055.XX | | 12 | | | | | | |
| FL 013.XX | 12 | | | | | | | |
| FL 014.XX | 12 | | | | | | | |
| FL 016.XX | 13 | | | | | | | |
| FL 022.XX | | | 21 | | 24 | | | |
| FL 026.XX | | | 18 | | 11 | | | |
| FL 032.XX | | | | | 22 | | | |
| FL 055.XX | | 12 | | | | | | |
| FL 065.XX | | | | | | 25 | 25 | |
| FL 066.XX | | | | | | 25 | | |
| TE 023.XX | | | 21 | | 22 | | | |
| TE 033.XX | | | | | 24 | | | |
| TE 072.XX | | | | | 23 | | | |
| TE 082.XX | | | 21 | | 26 | | | |
| TE 091.XX | | | | 19 | 12 | | | |
| TE 092.XX | | | 17 | 12 | 10 | | | |
| TE 093.XX | | | | 14 | 11 | | | |
| TE 092.X1 | | | 17 | 12 | 10 | | | |
| TE 093.X1 | | | | 14 | 11 | | | |
| TE 094.XX | | | | 16 | 8 | | | |
| TD F 012.XX | 5 | | | | | | | |
| TD F 014.XX | 5 | | | | | | | |
| TD F 015.XX | 5 | | | | | | | |
| TD F 022.XX | | | 19 | | 21 | | | |
| TD F 032.XX | | | | | 21 | | | |
| TD F 033.XX | | | | | 21 | | | |
| TD F 055.XX | | 14 | | | | | | |
| TD F 061.XX | | | | | | 22 | 21 | |
| TD F 065.00 | | | | | | 21 | 21 | |
| TD F 066.XX | | | | | | 22 | | |
| TD F 091.XX | | | | 14 | 11 | | | |
| TD 012.XX | 5 | | | | | | | |
| TD 014.XX | 5 | | | | | | | |
| TD 015.XX | 5 | | | | | | | |
| TD 022.XX | | | 19 | | 21 | | | |
| TD 032.XX | | | | | 21 | | | |
| TD 033.XX | | | | | 22 | | | |
| TD 055.XX | | 14 | | | | | | |
| TD 061.XX | | | | | | 22 | 21 | |
| TD 065.XX | | | | | | 21 | 21 | |
| TD 066.XX | | | | | | 22 | | |
| TD 091.XX | | | | 14 | 11 | | | |

HODNOTY PRŮTOKŮ VODOVODNÍCH BATERIÍ RAVAK

Průtok je udáván v l/min při tlaku 0,3 MPa

| RAVAK code | Umyvadlo | Bidet | Vana | Hlavová sprcha | Ruční sprcha | OUT 1 | OUT 2 | OUT 3 |
|------------|----------|-------|------|----------------|--------------|-------|-------|-------|
| CR 011.XX | 8 | | | | | | | |
| CR 012.XX | 8 | | | | | | | |
| CR 013.XX | 8 | | | | | | | |
| CR 014.XX | 8 | | | | | | | |
| CR 015.XX | 8 | | | | | | | |
| CR 016.XX | 14 | | | | | | | |
| CR 019.XX | 8 | | | | | | | |
| CR 022.XX | | | 16 | | 17 | | | |
| CR 025.XX | | | 16 | | 11 | | | |
| CR 026.XX | | | 15 | | 11 | | | |
| CR 032.XX | | | | | 20 | | | |
| CR 055.XX | | 15 | | | | | | |
| CR 063.XX | | | | | | 20 | 20 | |
| CR 064.XX | | | | | | 20 | | |
| CR 065.XX | | | | | | 21 | 20 | |
| CR 066.XX | | | | | | 21 | | |
| CR 067.XX | | | | | | 16 | 17 | 17 |
| CR 080.XX | | | 19 | | 14 | | | |
| CR 112.X1 | 7 | | | | 6 | | | |
| CL 011.XX | 11 | | | | | | | |
| CL 012.XX | 11 | | | | | | | |
| CL 016.XX | 7 | | | | | | | |
| CL 022.XX | | | 15 | | 16 | | | |
| CL 032.XX | | | | | 17 | | | |
| CL 055.XX | | 10 | | | | | | |
| CL 061.XX | | | | | | 22 | 23 | |
| CL 065.00 | | | | | | 20 | 20 | |
| CL 066.00 | | | | | | 20 | | |
| WF 025.00 | | | 19 | | 11 | | | |
| RS 025.00 | | | 19 | | 12 | | | |
| FM 016.00 | 18 | | | | | | | |
| FM 080.00 | | | 16 | | 12 | | | |
| BM 011.X1 | 11 | | | | 6 | | | |
| BM 040.X1 | | | | | 9 | | | |
| DS 091.00 | | | | 15 | 8 | | | |
| DS 092.00 | | | | 15 | 8 | | | |

ES 019.XX.O1
ES 021.XX.O1

ES/EL 062.XX.O1

ES/EL 061.XX.O2
TD / TD F / CL: 061.XX

CR 064.00

CR 063.XX

RB 07B.50

ES/EL 019.00.O1.RB07B

RB 07C.50

ES 063.XX.O2.RB07C ES 067.XX.O3.RB07C

RB 07D.50

ES/EL 065.XX.O2.RB07D.+S ES/EL 068.XX.O3.RB07D.+S

RB 07E.50

ES/EL 065.XX.O2.RB07E

RB 07F.50

ES/EL 068.XX.O3.RB07F

RB 070.50

CR / TD / TD F / CL: 066.XX CR / TD / TD F / CL: 065.XX

RB VARI 072.50

FL 066.XX FL 065.XX

RB Multi 071.50

CR 067.00