

Instruction manuals for holder for glass plate

SIMPLE HOLDER (36305)

DOUBLE HOLDER (36306)

Glass-holder can be used to hold or carry objects such as a window, mirror, door, etc. Use the holder can also create a temporary handrail as in bathrooms or toilets. The condition is smooth and clean surface of an object or place at which the holder is attached.

USE:

1. Pull lever bracket (bracket for easy moving part of the handle) and attach the bracket to clean and smooth the surface of the object to which you want to place the bracket.
2. Lightly press the bracket and tighten lever (handle). This creates a negative pressure under a suction cup and the holder is thus secured.
3. Now you can object to transfer or bracket as a handle.
4. To remove the bracket from the article just unlock the handset (movable handle).

TECHNICAL DATA:

Item NO.	Average	Weight	Maximum load
36305	Ø 11,5 cm	0,4 kg	25 kg
36306	2 x Ø 11,5 cm	0,8 kg	50 kg

